





Setup scan to email for Fuji Xerox copier


1. Type the copier ip in the URL of a browser.



2. Click Properties – and type Username : 11111 and Password : x-admin



3. Click Connectivity – Protocols – SMTP Server.



4. Set SMTP Server IP Address / Host Name : smtpserver.hkbu.edu.hk
5. Set the Port Number for sending E-mail : 25
6. Set the Port Number for receiving E-mail : 25
7. Disabled – SMTP SSL / TLS Communication.
8. Set Machine's E-mail Address : xxxx@xxx.xxx
9. Scroll down the page and click Apply button.

